

VICTORIAN COUNTRY REGIONAL NETWORK -- SIGNAL LOCATIONS

Regional Branches		DOWN MOVEMENT		
Signal Number	Signal Type	Km	GPS	Track
DO NOT USE THIS DATA FOR OPERATIONAL PURPOSES WITHOUT CHECKING				
SIGNAL TYPES DEFINED GENERICALLY ONLY				
CLICK ANYWHERE IN THE TABLE TO RETURN TO THE RELEVANT DRAWING				
YELTA LINE				
BATESFORD				
GHERINGHAP				
GHP31	Home Junction	83.549	-38.074707,144.232085	Single Line
GHP U31				
MEREDITH				
1	Distant (Semaphore)	113.241	locked 'off'	Single Line
2	Home (Semaphore)	113.739	locked 'off'	Single Line
BALLARAT		Incorporating BALLARAT EAST & NORTH BALLARAT JCN		
AL1147	Repeating (Med. speed)	151.222	-37.561586,143.905161	Single Line
BAT50	Home Junction	154.778	-37.559284,143.871266	Single Line
BAT16	Starter	155.869	-37.558334,143.858889	Platform 2
BAT18	Starter	155.869	-37.558372,143.858868	Road 2
BAT20	Starter	155.869	-37.558283,143.858585	Platform 1
NBJ6	Home Junction	156.839	-37.550802,143.854303	Main
CRESWICK				
AM1733	Automatic	173.561		Single Line
CWK30	Home	174.857		Single Line
CLUNES				
CLV6	Automatic	190.225		Single Line
CLV30	Home	192.086		Single Line

Regional Branches		UP MOVEMENT			RETURN TO CRN MENU
Signal Number	Signal Type	Km	GPS	Track	
DO NOT USE THIS DATA FOR OPERATIONAL PURPOSES WITHOUT CHECKING					
SIGNAL TYPES DEFINED GENERICALLY ONLY					
CLICK ANYWHERE IN THE TABLE TO RETURN TO THE RELEVANT DRAWING					
BATESFORD					
83/14	Home	81.841	-38.076455,144.251317	Geringhap Loop	
GE834	Repeating (Med. speed)	83.549	-38.074707,144.232085	Single Line	
GHERINGHAP					
GHP33	Home Junction	84.632	-38.072356,144.220221	Single Line	
GHP U33					
GHP35	Repeating	86.135	-38.064525,144.206260	Single Line	
MEREDITH					
3	Starter	114.133	locked 'off'	Main	
4	Starter (o.o.s)	114.133	locked 'off'	Loop	
5	Home (Semaphore)	114.629	locked 'off'	Single Line	
6	Distant (Semaphore)	115.129	locked 'off'	Single Line	
BALLARAT		Incorporating BALLARAT EAST & NORTH BALLARAT JCN			
BAT48	Home Junction	155.147	-37.559636,143.867047	Melbourne Main	
BAT26	Home Junction	155.760	-37.558964,143.860292	Road 2	
BAT24	Starter	155.720	-37.559236,143.861156	Platform 2	
BAT24BI	Repeater	155.750	-37.558624,143.859664	Platform 2	
NBJ8	Home Junction	156.478	-37.553795,143.855609	Main	
NBJ4	Home	157.191	-37.547681,143.853255	Yelta Main	
NBJ112	Outer Home	160.104	-37.521871,143.850820	Single Line	
AM1260	Automatic	161.998	-37.504791,143.852476	Single Line	
CRESWICK					
CWK32	Home	174.742		Single Line	
AM1760	Automatic	176.096		Single Line	
CLUNES					
CLV10	Home	192.463		Single Line	
CLV12	Shunt	192.463		Engineers Siding	
CLV26	Automatic	193.705		Single Line	
continued on Page 2					

VICTORIAN COUNTRY REGIONAL NETWORK -- SIGNAL LOCATIONS

Regional Branches					DOWN MOVEMENT					RETURN TO CRN MENU
Signal Number	Signal Type	Km	GPS	Track	Signal Number	Signal Type	Km	GPS	Track	
MARYBOROUGH					MARYBOROUGH					
AM2207	Automatic	220.670		Single Line	MYB8	Starter	223.121		Single Line	
NE1911	Repeating fx:Y/Y	-191.100		Ararat Branch	MYB10	Home Junction [s][v]	223.789		Main	
MYB2	Home (med. speed only)	-187.802		Ararat Branch	MYB12	Shunt	223.790		No2 Road	
MYB4	Home	222.602		Single Line	MYB20	Shunt			Stabling Compound	
MYB6	Home [s][v]	223.650		Single Line	MYB22	Shunt			Sidings	
MYB30	Home Jcn [s][v]	224.709		Main	MYB26	Home Junction	224.772		Main	
MYB32	Shunt			No2 Road	MYB28	Home (End TO)	226.130		Single Line	
					N2274	Repeating	227.077		Single Line	
DUNOLLY					DUNOLLY					
DLY6	Home			Single Line (dg)	DLY26	Home	246.770		Single Line	
DLY36	Home Junction	246.331		Single Line	DLY28	Home	-210.352		Inglewood Branch	
DLY38										
EMU LOOP					EMU LOOP					
EMU1	Repeating			Single Line	EMU2	Repeating			Single Line	
DONALD					DONALD					
DON1	Repeating	336.112		Single Line	DON2	Repeating	338.637		Single Line	
OUYEN					OUYEN					
1	Home (Semaphore)	508.102		Single Line	3	Starter	508.537		Main	
2	Home (Semaphore)	-472.070		Murrayville Branch	6	Home	509.528		Single Line	
5	Starter	509.476		Single Line						
MANANGATANG BRANCH										
INGLEWOOD					INGLEWOOD					
ING1	Repeating			Single Line	ING2	Repeating			Single Line	
BOORT					BOORT					
A	Home (Semaphore)			Single Line	F	Home (Semaphore)			Single Line	
					E	Home (Semaphore)			Single Line	
MANANGATANG					MANANGATANG					
					@	Automatic Starter			Single Line	
HOPETOUN BRANCH										
WARRACKNABEAL					WARRACKNABEAL					
A	Home	488.094		Single Line	J	Home			Single Line	
					H	Home			Single Line	